


APPLICATIONS

Air-air boosters are used for instance in seal or burst tests, or to increase power in cylinders to avoid having to replace them with ones with a larger diameter.

RECOMMENDED CIRCUIT


- ① Air-air booster
- ② Tank
- ③ Pressure regulator
- ④ Pressure regulator
- ⑤ FRL units

To achieve the correct booster pressure ratio, regulators 3 and 4 must have the same pressure.




COMPONENTI

- ① FRONT CYLINDER HEAD: 2011 neutral anodised aluminium
- ② FRONT LINING: Ø50/Ø63 profiled anodised aluminium
- ③ INTERMEDIATE CYLINDER HEAD: 2011 neutral anodised aluminium
- ④ REAR LINING: Ø100 profiled anodised aluminium
- ⑤ SILENCER: nickel-plated brass
- ⑥ BOLT: white galvanised steel
- ⑦ REAR CYLINDER HEAD: 2011 neutral anodised aluminium
- ⑧ EXCHANGER PISTON: brass
- ⑨ EXCHANGER GASKET: NBR rubber
- ⑩ PISTON GASKET: NBR rubber
- ⑪ GUIDE BANDS: phenolic resin
- ⑫ PISTON Ø50/Ø63: 2011 aluminium
- ⑬ PISTON ROD Ø16: C45 ground chrome steel
- ⑭ FILTER: sintered bronze
- ⑮ PISTON GASKET Ø100: NBR OR compound and plastoferrite band
- ⑯ PISTON Ø100: 2011 aluminium
- ⑰ VNR RING NUT: nickel-plated brass
- ⑱ VNR SPRING: stainless steel
- ⑲ VNR PISTON: brass
- ⑳ VNR SOLID GASKET: CSC polyurethane




DIMENSIONS: Z5208100500400

G1/8 = air inlet 1
 G1/4* = air inlet 2
 G1/4° = boosted air outlet



DIMENSIONS: Z5208100630400


G1/8 = air inlet 1
 G1/4* = air inlet 2
 G1/4° = boosted air outlet




TANK FILLING CURVES

The graphs below refer to the filling of a 10-litre tank and show the pressure increase ratio $P_2:P_1$ as a function of time [s]. When calculating the tank filling time, the ratio $P_2:P_1$ must have 2 values. The first value is the ratio of the initial tank pressure "Pi" to the booster supply pressure "Pa"; the second value is the ratio of the final tank pressure "Pf" to the supply pressure "Pa".

Z5208100630400



Z5208100500400



The data required to calculate the tank filling time are thus:

- P_a = air/air booster supply pressure
- P_i = initial pressure in the tank
- P_f = Final pressure in the tank
- V = Volume of the tank

EXAMPLE OF CALCULATION

Let us assume we need to fill a 50 litre tank with our booster ratio 4:1 (Z5208100500400) at a pressure of 5 bar. The tank has an initial pressure of 6 bar, which needs to be increased to 15 bar. In short,

- Pa = 5 bar
- Pi = 6 bar
- Pf = 15 bar
- V = 50 l

Now let us calculate the initial and final ratios P2:P1.

$$P2:P1(i) = Pi:Pa = 6/5 = 1.2$$

$$P2:P1(f) = Pf:Pa = 15/5 = 3$$

Now let us go to the relevant booster graph and read the time value in relation to the pressure ratios we have just calculated.

With P2:P1(i), time Ti = 15 s

With P2:P1(f), time Tf = 130 s

The difference between the final time and the initial time gives the value T to be inserted in the final formula:


$$T = Tf - Ti = 130 - 15 = 115 \text{ s}$$

The filling time Tr for a 50 litre tank will be:


$$Tr = T * V / 10 = 115 * 50 / 10 = 575 \text{ s}$$

FLOW RATE CHARTS

Z5208100500400




Z5208100630400



SET OF SPARE GASKETS


Code	Bore	Refer
Z5208K__100	50-63	① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨

__ = Bore


ACCESSOIRES

The air-air booster is available with 1 or 2 regulators, complete with G1/8 or G1/4 male-male fittings, pressure gauge and 12 bar bit.

Z5208100__0401



Z5208100__0402

